

## Product Data Sheet

### SORB<sup>®</sup>XT Safety-Kit QC

Article	SORB <sup>®</sup> XT Safety-Kit QC
Article No.	100502EN
Sachet (mm)	310x210x70
Pillow (mm)	300x200x50
Weight	1,00 Kg
Absorption capacity	2,60 L



## Product Information:

### Recommended use

- 2L sachet: Mobile first aid for smaller leakages
- Barrier pillow: On usual grounds and on water as a barrier and absorbent
- Quick-container: Set-up container under the area of expected leakage or spill

### Application

- Spread out SORB<sup>®</sup>XT evenly over the leaked substance and work into the material
- Place the pillows directly on the area of contamination and wait until it has reached its full absorptive capacity (the pillow will be entirely in the color of contaminated material)
- The pillow can be applied on all mentioned fields plus on water surfaces

### Storage

- Store in an dry place with low humidity to avoid mold

### After application

- Skim off or sweep up the substance from the surface
- Collect the substance with pick-up spatula and put it into a disposal bag/ collect the pillow with single-use gloves and put it into a disposal bag
- Dispose of the contaminated material following the respective valid laws and local regulations
- Clean the quick-container and fold it back to initial shape (reusable)

### Properties

- "QC" version includes a mobile, foldable container for "planned" leakages up to 3L. The Quick Container is set up within seconds and has a resistant foil against oils and fuels. "QC" Kit contains the following:
- 1x 2L Sachet of 100% organic SORB<sup>®</sup>XT fibre, 1x Barrier pillow (filled with 100% organic SORB<sup>®</sup>XT fibre), 1x Quick container, 1x Single-use gloves, 2x Disposal bag