

## Product Data Sheet

### SORB<sup>®XT</sup> PP-Pillow

|                     |                               |
|---------------------|-------------------------------|
| Article             | SORB <sup>®XT</sup> PP-Pillow |
| Article No.         | 100401/PP                     |
| Dimensions (mm)     | 400x600x50                    |
| Weight              | 1,00 kg                       |
| Absorption capacity | 13,50 l                       |



## Product Information:

### Recommended use

- surface protection / mobile emergency aid for smaller quantities on solid ground and on water
- as a barrier and absorption medium for use on calm and flowing water, both salt and fresh water
- for preventive measures

### Application

- place the pillow directly on the contaminated area and wait until it has reached its full absorption potential (the pillow will be completely in the colour of the contaminated material)
- areas of application: plants, companies, environmental protection, traffic, on water/roads/asphalt, normal floors, industrial sites, special floors, water surfaces

### After application

- collect the pillow with disposable gloves
- please dispose of the contaminated material in accordance with the applicable laws and municipal regulations

### Storage

- store in a dry place with low humidity

### Properties

- filled with finely padded polypropylene
- hydrophobic
- floats on water
- keeps contaminated substances bound after use